

Malö standard sail dimensions

	P	E	I	J
Malö 40 H	11,30	3,50	12,65	3,80
Malö 40 79 --	11,30	3,50	12,80	3,80
Malö 40 -78	10,40	3,50	11,70	3,78
Malö 96	11,20	3,75	12,80	3,75
Malö 50 low rig	10,20	4,20	12,00	4,30
Malö 50	11,10	4,20	13,00	4,30
Malö 34	11,10	3,70	13,10	3,80
Malö 36 Furling	12,50	4,70	14,70	4,20
Malö 36	12,50	4,45	14,70	4,20
Malö 106	12,60	4,20	14,40	4,30
Malö 116	13,90	4,30	15,75	4,75
Malö 37	13,80	4,65	14,90	4,15
Malö 37 Furling	13,80	4,65	14,90	4,15
Malö 38	12,50	4,15	14,60	4,15
Malö 39 Furling	13,425	5,10	15,70	4,65
Malö 39 STD	13,60	4,85	15,70	4,65
Malö 40 2005	14,25	5,00	15,82	4,68
Malö 40 2005 Furling	14,25	5,00	16,00	4,60
Malö 41/43	14,50	5,10	16,75	4,85
Malö 41/43 Furling	14,345	5,10	16,75	4,85
Malö 42	15,50	5,25	17,60	5,15
Malö 42 Furling	15,39	5,50	17,60	5,15
Malö 45/46	16,10	5,65	18,40	5,30

Malö Yachts cannot guarantee the exact dimensions of every boat and the above table should only be used as a guide for quotation requests. Customers are strongly advised to measure their boat carefully prior to order.